



CE

185 LCT

INTRODUCTION

- The 185 LCT Lan cable tester is a newly designed tool that can easily test the correct pin configuration of the RJ45/RJ11 modular cables, 10/100 base-T cable and Token Ring cable etc.
- By comparing one transmitting end and the corresponding receiving end, the 185 LCT Lan cable tester also can test installed cable far away by using the remote receiving unit.
- The 185 LCT provides the variety for wiring check, such as cable continuity, open status, short status and miss-wired.

FEATURES

- Designed for RJ45/RJ11 modular cables, 10/100 base-T cable and Token Ring cable etc.
- The Lan cable tester can verify cable continuity, open, short circuit and miss-wired.
- The remote receiving unit is available for installed cables far away either on the wall plates or on the patch panels.
- Auto and manual scan function.
- Ground wire test.
- Lock status function.
- Buzzer sound warning for wire status.
- Display: LED indication for wire status.
- EN61326-1

SPECIFICATIONS

Display	LED
Operating Temperature	0°C~40°C
Power Source	9V (6F22,006P) battery x1
Dimensions	Master unit 132(L)x 55(W)x 39(D)mm Remote receiving unit 74(L)x 30(W)x 25(D)mm
Weight	Master unit: 148 g Remote receiving unit: 33 g
Accessories	Instruction manual Pouch Battery

OPERATION

Loopback test

- Plug one end of the testing cable into the Rj45 jack of sourcing end on the master unit and another end of the testing cable into the RJ-45 jack of receiving end on the master unit.
 - Press the "⏻" button, the master unit will start a sequential scanning process if the master unit is in "auto-scanning" mode.
 - Press the "⏻" button, the pin1 LED lamps of the LED indicators will be alight if the master unit is in "manual-scanning" mode.
- Note: When the battery power is low, the testing results may not be correct. Please replace with a new battery.
- You can choose a auto-scanning mode or a manual-scanning mode by pressing the "AUTO" button or the "MANU" button.
 - The Lock function is available in "auto-scanning" mode.
 - When the loop is "OPEN", you will hear the sound of the buzzer.

Remote test

- Plug one end of the testing cable into the Rj45 jack of sourcing end on the master unit and another end of the testing cable into the RJ-45 jack of the remote receiving unit, then make tests.
- Read the testing results from the LED indicator on the remote receiving unit.

Test result

a. Continuity

Pin 3 is continued



1 2 3 4 5 6 7 8 GND



c. Short

Pin 5 and 6 are shorted



1 2 3 4 5 6 7 8 GND



b. Open

Pin 4 is opened



1 2 3 4 5 6 7 8 GND



d. Miss-wired

Pin 1 and 7 are miss-wired



1 2 3 4 5 6 7 8 GND



Loopback Test

Remote Test

EMPIRE TRADING AGENCY
No. 110, LAYARDS BROADWAY,
COLOMBO 14.

TEL (GENERAL): 011 2 433 047, 011 2 343 701

TEL (SALES) : 011 5 330 470 -71

FAX : +94-(0)11-2 431 180

E-MAIL : empita@slt.lk